



Quick Coupling X Reference Guide

Hyd Conn	Parker	Faster	Stucchi	Pirtek	Ryco	Holmbury	Eaton	Fluid Conn	Manuli	DNP	Snap-Tite	Safeway	Stauff	Inteva
S1	6600	ANV	BIR	6600	R82/81	IA	5600	QA	A	PAV1	61	S56	IA	101
S1Y	8010 DC	4NV	BIR PC		R81 CP	IAPC	FD72	QA PC	AP	PKK1	63	S71	HU	105
PK (Poppet)	4000	NV	IR V	4000	R80	DIN V		QD	N	PDV1	60	S40	ID	104
PK (GF)		NV	IR V (FA)	4000		DIN V	FD42	QDF		PDV1		S25		104
S4 (Ball)	4000	NS	IR	4000	R91	DIN B			N	PDS1		S41		104
S4 (GF)		NS	IR (FA)	4000		DIN B				PDS1				104
S5	4200	PV/PS	IRS	6602P	R91/94/96	P	FD71	QAF PPS	AF	PPV1	61DC	S45	HP	105
3CFPV	RSD	3CFPV				IAP		QAF MSM	ARM	PPK3			UXS	
PBR		NZV	IRN	9500	R140			QPBR		PNZ1			HG	
S2-G	H62/63	HNV	IRB	F6602	R55	IB	FD45	QB	B	PBV1	72	S105	IB	103
S2-N	H62/63	HNV	IRB	60B	R45	IB	FD45	QB	B	PBV1	72	S105	IB	103
S2-GB	BH60/61	HNV	IRBO		R55B	IBB	FD45		B	PBVM	B72	BS105	IB	103
S2-NB	BH60/61	HNV	IRBO		R45B	IBB	FD45		B	PBVM	B72	BS105	IB	103
S2-GS	SH62/63	HNV			R55S		FD45				S72	SS105	IB	
S2-GSS	SSH62/63	HNV	IRBX	SF6600	R55SS	IBS	FD45	S-QB	B	PBVX	SS72		IB	103
S2-NSS	SSH62/63	HNV	IRBX		R45SS	IBS	FD45	S-QB	B	PBVX	SS72		IB	103
FF-G	FEM-FB	FFH	FIRG	7000**	R110	HQ	FD89	QFF	FH	PLT4	74	FFE	FF/FH	131
FF-U	FEM-FO	FFH	FIRG	7500**	R110	HQ	FD89	QFF	FH	PLT4	74	FFE	FF/FH	131
FFY	FEC	3FFH	APM	7200		HCP	FFCUP	QFM-HCP	FP	PLKJ4	CP74	FFEC	FU	131
S300	3000	PVVM	IVHP	3000	R100	PSP	HP3	QJ	SC	PVM4	76	S35	HI	202
VV		VV				PLC		QS-VV		VDV1			HB	
VVS		VVS				PTC		QS-VVS	SH	VVV1			HH	
CVV	QHPA	CVV	VD		R120	HS		QS HS	SG	PVV3			HS	205
ST	ST						ST							
TM	TH			9000	R130	F		QH-F						
VEP	FET		VEP			HFT	FD96	QFF-HFT	FS	PST4			FT	231
TF		UHP150				KM				PCJ6			HD	
PD	PD	DF				DTP	FD90		D				IB	136

** Check Nipple Diameter